

Clean Earth Sampling Protocol Georgia

PARAMETERS	TPH - GRO (GA Sites)	TPH - DRO (GA Sites)	TRPH (Florida Sites)	PAH's	TOTAL METALS - Arsenic, Chromium and Lead	TOTAL METALS - Cadmium, Selenium and Silver	TOTAL METALS - Arsenic, Barium, Lead, Mercury, Selenum and Silver	BTEX	PCB's
METHODS (1)		8015	8015	FLPRO	8270D	6010	6010/7471	8260B	8082A
FREQUENCY									
Gasoline or Aviation Fuel	1 Sample per every 280 tons Sample metals per project	1	X (2)		X (2)		X (3)		X (3)

(1) The methods provided are standard EPA methods. The method revisions are subject to change and the most current method should always be utilized by the laboratory.

(1) Sites located in Georgia are required to analyze TPH-GRO / TPH-DRO and sites in Florida may analyze FLPRO.

(2) TCLP may be required based on the total levels of Benzene and/or metals.

NOTE - Based on current and historical site usage, additional analysis may be requested.